


2161 - BLACK ONE**BRO.OVER****BROWN RED****BROWN****MINIPASS****PASS****TECH3****Programmazione radiocomando**

1. Premere e mantenere premuti contemporaneamente i tasti A e B del BLACK ONE finché il led inizia a lampeggiare; rilasciare i tasti.
 2. Posizionare i radiocomandi come in figura 2 e premere il tasto del radiocomando originale da duplicare finché il led del BLACK ONE inizia a lampeggiare rapidamente.
 3. Con il led del BLACK ONE lampeggiante, premere il tasto dove si vuole programmare il tasto appena acquisito.
- PS: Per programmare i restanti tasti ripetere la procedura precedente.*

Programmazione a distanza

1. Posizionarsi vicino alla ricevente originale.
2. Premere e mantenere premuti contemporaneamente i tasti C e D del BLACK ONE finché il led si spegne; rilasciare i tasti.
3. Mentre il led lampeggia rapidamente, premere il tasto programmato; attendere che il led smetta di lampeggiare.

Programmazione sulla centralina

1. Premere il tasto PGM, il led si accende; rilasciare il tasto.
2. Entro 10 secondi premere il tasto del BLACK ONE programmato finché il led della centralina inizia a lampeggiare; rilasciare il tasto.
3. Attendere 10 secondi per uscire dalla modalità di programmazione.

RadioreMOTE programming

1. Simultaneously press and hold in the A and B buttons of the BLACK ONE until the LED begins to flash.
 2. Place the radioreMotes as in figure 2 and press the key of the original radioreMOTE to be duplicated until the led of BLACK ONE starts blinking quickly.
 3. While the led of BLACK ONE is blinking, press the key where you want to program the key just acquired.
- P.S.: Please repeat the previous procedure to program the remaining keys.*

Remote programming

1. Place yourself near the original receiver.
2. Hold down C and D keys of BLACK ONE simultaneously until the led turns off; release the keys.
3. While the led is blinking quickly, press the programmed key; wait for the led to stop blinking.

Programming on the central unit

1. Press PGM key, the led light up; release the key.
2. Within 10 seconds, press the programmed BLACK ONE button until the led on the central unit starts blinking; release the button.
3. Wait 10 seconds to exit programming mode.