


2161 - BLACK ONE

PTX4 BLU



PTX4 PINK

**Programmazione radiocomando**

1. Premere e mantenere premuti contemporaneamente i tasti A e B del BLACK ONE finché il led inizia a lampeggiare; rilasciare i tasti.
 2. Posizionare i radiocomandi come in figura 2 e premere il tasto del radiocomando originale da duplicare finché il led del BLACK ONE inizia a lampeggiare rapidamente.
 3. Con il led del BLACK ONE lampeggiante, premere il tasto dove si vuole programmare il tasto appena acquisito.
- PS: Per programmare i restanti tasti ripetere la procedura precedente.*

Programmazione a distanza sulla centralina

1. Premere il tasto funzionante del telecomando originale.
2. Entro 10 secondi, premere tramite una punta il tasto nascosto al centro dei quattro tasti del radiocomando originale.
3. Premere 2 volte il tasto del BLACK ONE programmato.

Programmazione sul motore

1. Tenere premuto il tasto DOOR CODE fino alla fine della procedura.
2. Premere 2 volte il tasto del BLACK ONE programmato.
3. Rilasciare il tasto DOOR CODE.

Programmazione sulla centralina

1. Tenere premuto il tasto SW1 sulla centralina fino alla fine della procedura.
2. Premere 2 volte il tasto del BLACK ONE programmato.
3. Rilasciare il tasto SW1.

Radioremove programming

1. Simultaneously press and hold in the A and B buttons of the BLACK ONE until the LED begins to flash.
 2. Place the radioremotes as in figure 2 and press the key of the original radioremove to be duplicated until the led of BLACK ONE starts blinking quickly.
 3. While the led of BLACK ONE is blinking, press the key where you want to program the key just acquired.
- P.S.: Please repeat the previous procedure to program the remaining keys.*

Remote programming on the central unit

1. Press the working key of the original radioremove.
2. Within 10 seconds, press the hidden key at the center of the four keys of the original radioremove using a pointed object.
3. Press twice the programmed key of BLACK ONE.

Programming on the motor

1. Hold down DOOR CODE key until the end of the procedure.
2. Press twice the programmed key of BLACK ONE.
3. Release DOOR CODE key.

Programming on the central unit

1. Hold down SW1 key on the central unit until the end of the procedure.
2. Press twice the programmed key of BLACK ONE.
3. Release SW1 key.