


2161 - BLACK ONE

GTX4



MOOVO



TX3



TX4

**Programmazione radiocomando**

1. Premere e mantenere premuti contemporaneamente i tasti A e B del BLACK ONE finché il led inizia a lampeggiare; rilasciare i tasti.
 2. Posizionare i radiocomandi come in figura 2 e premere il tasto del radiocomando originale da duplicare finché il led del BLACK ONE inizia a lampeggiare rapidamente.
 3. Con il led del BLACK ONE lampeggiante, premere il tasto dove si vuole programmare il tasto appena acquisito.
- PS: Per programmare i restanti tasti ripetere la procedura precedente.*

Programmazione a distanza

1. Posizionarsi vicino alla ricevente originale.
2. Premere e mantenere premuti contemporaneamente i tasti C e D del BLACK ONE finché il led si spegne; rilasciare i tasti.
3. Mentre il led lampeggia rapidamente, premere il tasto programmato; attendere che il led smetta di lampeggiare.

Programmazione sulla centralina

1. Premere e mantenere il tasto P1 o MEMO finché il led della centralina si accende a luce fissa; rilasciare il tasto.
2. Premere il tasto del BLACK ONE programmato, il led della centralina si spegne.
3. Attendere 1 secondo e premere di nuovo il tasto del BLACK ONE programmato, il led della centralina effettuerà 3 lampeggi di conferma.
4. Attendere 10 secondi per completare la programmazione.

RadioreMOTE programming

1. Simultaneously press and hold in the A and B buttons of the BLACK ONE until the LED begins to flash.
 2. Place the radioreMotes as in figure 2 and press the key of the original radioreMOTE to be duplicated until the led of BLACK ONE starts blinking quickly.
 3. While the led of BLACK ONE is blinking, press the key where you want to program the key just acquired.
- P.S.: Please repeat the previous procedure to program the remaining keys.*

Remote programming

1. Place yourself near the original receiver.
2. Hold down C and D keys of BLACK ONE simultaneously until the led turns off; release the keys.
3. While the led is blinking quickly, please press the programmed key. Wait for the led to stop blinking.

Programming on the central unit

1. Hold down P1 key or MEMO key until the led of the central unit turns on steadily; release the key.
2. Press the programmed key of BLACK ONE, the led of the central unit turns off.
3. wait 1 second and press the programmed key of BLACK ONE again, the led of the central unit will blink 3 times for confirmation.
4. Wait 10 seconds to complete the programming.