


2161 - BLACK ONE

NEO



TWIN



VARIO MARS



VARIO OCEAN



VARIO

**Programmazione radiocomando**

1. Premere e mantenere premuti contemporaneamente i tasti A e B del BLACK ONE finché il led inizia a lampeggiare; rilasciare i tasti.
 2. Posizionare i radiocomandi come in figura 2 e premere il tasto del radiocomando originale da duplicare finché il led del BLACK ONE inizia a lampeggiare rapidamente.
 3. Con il led del BLACK ONE lampeggiante, premere il tasto dove si vuole programmare il tasto appena acquisito.
- PS: Per programmare i restanti tasti ripetere la procedura precedente.*

Programmazione a distanza

1. Posizionarsi vicino alla ricevente originale.
2. Premere e mantenere premuti contemporaneamente i tasti C e D del BLACK ONE finché il led si spegne; rilasciare i tasti.
3. Mentre il led lampeggia rapidamente, premere il tasto programmato; attendere che il led smetta di lampeggiare.

Programmazione sulla centralina

1. Premere il tasto sul ricevitore, il ricevitore emetterà un beep lungo.
 2. Premere il tasto del BLACK ONE programmato, il ricevitore emetterà un beep breve.
- Se si desidera programmare ulteriori radiocomandi ripetere la procedura dal punto 2 (entro 10 secondi dall'ultima memorizzazione).
Altrimenti attendere 10 secondi e provare i radiocomandi appena programmati.

RadioreMOTE programming

1. Simultaneously press and hold in the A and B buttons of the BLACK ONE until the LED begins to flash.
 2. Place the radioreMotes as in figure 2 and press the key of the original radioreMOTE to be duplicated until the led of BLACK ONE starts blinking quickly.
 3. While the led of BLACK ONE is blinking, press the key where you want to program the key just acquired.
- P.S.: Please repeat the previous procedure to program the remaining keys.*

Remote programming

1. Place yourself near the original receiver.
2. Hold down C and D keys of BLACK ONE simultaneously until the led turns off; release the keys.
3. While the led is blinking quickly, please press the programmed key. Wait for the led to stop blinking.

Programming on the central unit

1. Press the key on the receiver, the receiver will emit a long beep.
 2. Press the programmed key of BLACK ONE. The receiver will emit a short beep.
- If you want to program some more radioreMotes, please repeat the procedure from step 2 (within 10 seconds from the last storing).
Otherwise wait 10 seconds and test the just programmed radioreMotes.