


2161 - BLACK ONE



Programmazione radiocomando

1. Premere e mantenere premuti contemporaneamente i tasti A e B del BLACK ONE finché il led inizia a lampeggiare; rilasciare i tasti.
 2. Posizionare i radiocomandi come in figura 2 e premere il tasto del radiocomando originale da duplicare finché il led del BLACK ONE inizia a lampeggiare rapidamente.
 3. Con il led del BLACK ONE lampeggiante, premere il tasto dove si vuole programmare il tasto appena acquisito.
- PS: Per programmare i restanti tasti ripetere la procedura precedente.*

Programmazione a distanza (necessita di un radiocomando funzionante)

1. Premere tramite un oggetto appuntito il tasto nascosto sul retro del telecomando originale, la centralina emetterà un segnale acustico.
2. Entro 10 secondi premere il tasto del BLACK ONE programmato, la centralina emetterà un segnale acustico.
3. Attendere 10 secondi per completare la programmazione, la centralina emetterà 2 segnali acustici per conferma.

Programmazione sulla centralina

1. Premere il tasto PROG sulla centralina.
2. Premere il tasto del BLACK ONE programmato, la centralina emetterà un segnale acustico e il led si accende a luce fissa.
3. Attendere 10 secondi per completare la programmazione.

RadioreMOTE programming

1. Simultaneously press and hold in the A and B buttons of the BLACK ONE until the LED begins to flash.
 2. Place the radioreMotes as in figure 2 and press the key of the original radioreMOTE to be duplicated until the led of BLACK ONE starts blinking quickly.
 3. While the led of BLACK ONE is blinking, press the key where you want to program the key just acquired.
- P.S.: Please repeat the previous procedure to program the remaining keys.*

Remote programming (requires a properly working radioreMOTE)

1. Press the key on the back of the original remote control using a pointed object, the central unit will emit a beep.
2. Press the programmed key of BLACK ONE within 10 seconds, the central unit will emit a beep.
3. Wait 10 seconds to complete the programming, the central unit will emit 2 beeps for confirmation.

Programming on the central unit

1. Press PROG key on the central unit.
2. Press the programmed key of BLACK ONE, the central unit will emit a beep and the led will turn on steadily.
3. Wait 10 seconds to complete the programming.